

# Install support arm



- Before installation make sure to remove sprayer and spring out.
- Slide support arm through metal hose.

## Install support arm.

Make sure support arm slide to the white plastic ring.



# Adding black ring



- Once support arm is all the way down to white plastic ring, add black plastic clip slide it down to top of support arm. The black plastic clip, secures the support arm from moving.



## Adding black ring

Support arm should be snug fit not able to slide up once black ring is in placed.

Support arm in install now,

